

POWERFUL, QUIET, SAFE AND EASY TO USE

 AromaPlan®

Scent Diffuser

S L I M P R O


User Manual



FC CE RoHS

Introduction

This device adopts all-metal, double-threaded design, which is easy to operate. The product has an exquisite appearance and is perfectly integrated with various styles. It adopts touch and remote control dual control modes. It can be placed independently, and the fragrance is accurate and stable. Its main function is to create different fragrance styles for life, suitable for KTV, sales offices, shopping malls, 4S stores, hotels, airports, homes and health centers and other places.



FEATURES



Coverage:
up to 1.000 sq./ft.



Heatless & waterless
atomizer technology



Remote control.
Simple operation



Easily adjust scent
intensity and schedules




Noise reduction.
Ultra quiet technology






Energy saving and
high performance

Parameters

SIZE	Φ125*412(MM)
CAPACITY	110ML
N.W.	1.35KG
COVERAGE	up to 1.000 SQ./FT.
VOLTAGE	TYPE-C 5V-2A
POWER	6.0W
NOISE	≤38DB
PACKAGE	W465*D115*H153(MM)
LITHIUM BATTERY	10400MAH




Accessories

Item	Power Cable	User Manual	Remote Control	Atomizer Core
Diagram				

Precautions




Installation



1. Rotate the atomizer counterclockwise ①, lift up the atomizer and essential oil bottle, and take out the atomizer and essential oil bottle. ②
2. Hold the essential oil bottle and rotate it counterclockwise to take out the essential oil bottle to separate it from the atomizer, and fill it with essential oil (110ml, the upper limit). ③
3. Tighten the essential oil bottle and contain the essential oil clockwise with the atomizer. ④
4. Put the essential oil bottle and the atomizer into the machine, and tighten it clockwise (no need to correct the direction). ⑤
5. Set working hours and start using the equipment.

Description of LCD display



1. Operating instructions:

- ① Connect the power cord to the power adapter (5V-2A), this device has charging function.
- ② Connect the cord to the Type-C IN.
- ③ The power adapter is plugged into the power socket, and the device is powered on.

2. Controlling instruction:

In the default shutdown state, the battery will be charged when the battery is low, and the  key light flashes progressively. Then the light goes out when the battery is sufficient. When the machine is turned on and working while charging, the gear light is normally displayed. If there is no operation within 5 seconds, the indicator light will show charging status (the  key light will flash progressively).

The indicator light will return to the gear position light during operation.

Turn on: 'ON/OFF' button is blue light;

Turn off: 'ON/OFF' button is no light.

Low battery: 'ON/OFF' button is red and unable to turn on by tapping the key.

3. Touch mode/ remote control:

Touch the power button/press the **ON/OFF** button on the remote control to turn the machine on and off. If no power is connected at this time and the battery power is low, the switch indicator light will illuminate red.

The following operations are all in the power-on state:

- ①: Set 3 gears, touch " " in sequence, the corresponding light will turn on.
LOW gear: work for 20 seconds/pause for 60 seconds
MED gear: work for 30 seconds/pause for 40 seconds
HIGH gear: work for 40 seconds/pause for 30 seconds
- ②: Press the " " key, the corresponding indicator light will light up, and the countdown will be set to **2/4/8/12 hours** in sequence.
- ③: The corresponding button on the remote control will open the corresponding setting and correspond to the indicator light on the panel. After the remote control is successfully operated, the **RC** light flashes quickly and the buzzer beeps briefly.
- ④: Last settings will be reserved for next use.

Maintenance

In order to ensure the best diffusion effect, please check and maintain the device every six months, or when you replace a new fragrance, or when the diffusing effect gets weak as the following steps.

1. Take off the oil canister which is spent.
2. Fill industrial alcohol into the canister and clean it.
3. After clean the oil canister, refill canister with little alcohol and install it on the device then make the device stay in working status for 5-8 minutes.
4. Turn off the power when finish cleaning

Malfunction Debugging

Please try to solve the problem as below before fixing the machine.

BREAKDOWN	SOLUTION
Not working	-Please check that the power adapter is USB 5V-2A and that the Type-C and USB ports are plugged in correctly. -Check if device is not in work period.
No mist Mist gets weak	-Check if pump works or not, and if airflow from air outlet. -Check if atomizer core and oil tube are loosed or blocked. -Check if seal ring gets damaged or fell off.
Oil leakage	-Check if canister connects to atomizer closely. -Check if seal ring is deformed or damaged -Check if atomizer is damaged.
Abnormal noise	-Check if air pump is loosed, please fix it correctly. -Check if air pump is damaged, please replace a new one.

After-sale Service

The warranty is 1 year from the date of sale, not including device shell, adapter, electric wires, seal ring and the other vulnerable parts, as well as the damage caused by human or accident. Permanent maintaining for value will be provided if the machine exceed the warranty.

If there is any issue of after-sales, please contact authorized sales service in corresponding area, or contact Sales Center directly.

Attentions

Please read this manual in detail before using the device and keep it carefully.

1. Please do not use overloaded power sockets, broken wire and charger. It may endanger your safety and cause a fire, please replace in time if it happens.
2. Please do not try to modify, disassemble or repair the device in order to avoid damage to the device, if you are not a technician. If the device is abnormal, please check whether it is operated normally according to the user manual, or check according to the Malfunction Debugging. If it cannot be solved, please contact seller timely.
3. Please do not invert or tilt the device when used. If the device needs to be transported to other sites, please maintain and clean the device (see Maintenance for details) first before package and transportation, in case of oil leakage to damage the device.
4. Please maintain and clean the device regularly to ensure the device in best working states.

Instruction of Essential Oil

1. Before refill canister with essential oil, please turn off the device for 2 minutes till oil of atomizer back to canister then take off the oil canister.
2. It's recommended to control the amount of essential oil and run out within 45 days, in order to avoid the deterioration of essential oils by oxidation.

Warranty Card

This card is the warranty for device s quality, please fill it with actual information.

WARRANTY CARD ONE		WARRANTY CARD TWO	
Start Date of Warranty Period		Start Date of Warranty Period	
Malfunction Description		Malfunction Description	
Date of Verify		Date of Verify	
Maintenance Result		Maintenance Result	
Maintainer's Signature		Maintainer's Signature	



DOWNLOAD THE
INSTALLATION MANUAL
FOR YOUR DIFFUSER BY
SCANNING THE QR CODE

AROMAPLAN UNITED STATES
DISTRIBUTED BY FULLYSENSE LLC

CONTACT US AT:

E-mail: **support@fullysense.com**

Phone: **+1 (407) 233-4143**

WWW.FULLYSENSE.COM